



USER MANUAL
ENGLISH



—● TANK

—● STEEL BASE/AIR
FLOW CONTROL

REFILLING E-LIQUID

When you have about 25% of e-liquid remaining or you experience a slightly burnt taste, you will need to refill your tank with e-liquid

1. Always remove the battery from the tank before refilling with e-liquid.
2. Turn the tank upside-down and unscrew the steel base (air flow control).
3. Point and pour e-liquid into the sides of the tank. Fill to about 75% capacity of the tank. (DO NOT OVER-FILL OR POUR E-LIQUID INSIDE OF THE CENTER TUBE)
4. Screw the steel base back onto the tank.

AIR FLOW TECHNOLOGY

To adjust the air flow on your tank turn the steel base (Air Flow Control) by covering or uncovering the air holes to your desire.



CHANGING YOUR ATOMIZER

Once you experience a burnt taste, a decrease in flavor or vapor production, it may be time to replace your atomizer. It is recommended to change your atomizer head once every 1-4 weeks depending on use.

To get the truest flavor from your e-liquid, we also suggest changing your atomizer when switching e-liquid flavors.

1. Unscrew the steel base from the tank by turning it counterclockwise.
2. Grip the top of the atomizer head, located in the center of the tank, and unscrew the atomizer counterclockwise.
3. Once the old atomizer has been removed, screw in a new atomizer head by turning it clockwise into the center of your tank. Make sure not to over tighten the atomizer head as this may damage the rubber O-rings and cause leakage.
4. Screw the steel base clockwise back onto the bottom of the tank.



USER MANUAL
ESPAÑOL

CÓMO RECARGAR EL TANQUE CON E-LÍQUIDO

Cuando le quede aproximadamente el 25% del e-líquido o cuando sienta un ligero sabor a quemado, deberá recargar su tanque con el e-líquido.

1. Siempre retire la batería del tanque antes de recargarlo con el e-líquido.
2. Ponga el tanque hacia abajo y desenrosque la base de acero (el control del flujo de aire).
3. Apunte y vierta el e-líquido a los lados del tanque. Llene hasta aproximadamente el 75% de capacidad del tanque. (NO LO LLENE DEMASIADO NI VIERTA EL E-LÍQUIDO DENTRO DEL TUBO CENTRAL).

4. Enrosque la base de acero de nuevo en el tanque.

TECNOLOGÍA DE FLUJO DE AIRE

Para regular el flujo de aire en el tanque, gire la base de acero (control del flujo de aire) tapando o destapando los orificios de aire que desee.



—● TANQUE

—● BASE DE ACERO / CONTROL
DEL FLUJO DE AIRE



CÓMO CAMBIAR SU ATOMIZADOR

Es momento de cambiar el cabezal de su atomizador cuando experimente un sabor a quemado o la producción de vapor disminuya. Se recomienda cambiar el cabezal de su atomizador una vez cada 1 a 4 semanas, dependiendo del uso. A fin de obtener el sabor más auténtico del e-líquido, también sugerimos cambiar su atomizador cuando cambie los sabores del e-líquido.

1. Desenrosque la base de acero del tanque girándola en sentido contrario a las agujas del reloj.
2. Sujete la parte superior del cabezal del atomizador, ubicado en el centro del tanque, y desenrosque el atomizador en sentido contrario a las agujas del reloj.
3. Una vez que haya retirado el atomizador usado, enrosque un nuevo cabezal de atomizador girándolo en el sentido de las agujas del reloj en el centro de su tanque. Asegúrese de no ajustar demasiado el cabezal del atomizador ya que esto puede dañar las juntas de goma y ocasionar fugas.
4. Enrosque la base de acero en el sentido de las agujas del reloj nuevamente en el fondo del tanque.