



**VAPORFLO  
ATOMIZER**

USER MANUAL  
ENGLISH

### **CHANGING YOUR ATOMIZER HEAD**

Once you experience a burnt taste, a decrease in flavor or vapor production, it may be time to replace your atomizer head. It is recommended to change your atomizer head once every 14 weeks (depending on personal use).

To get the truest flavor from your e-liquid, we also suggest changing your atomizer head when switching e-liquid flavors.

1. To replace the atomizer head, turn your tank upside-down and unscrew and remove the air flow valve by turning it counterclockwise.
2. While still holding onto the air flow valve grip the top of the atomizer head and unscrew it counterclockwise to remove the atomizer head from the air flow valve.
3. Once the old atomizer has been removed, screw in a new atomizer head by turning it clockwise into the air flow valve until you feel resistance. Make sure not to over tighten the atomizer head as this may damage the rubber O-rings and cause leakage.
4. Screw the air flow valve back onto your tank by turning

it clockwise. Make sure not to over tighten.



**VAPORFLO  
ATOMIZER**

MANUAL DE USUARIO  
ESPAÑOL

### **CÓMO CAMBIAR EL CABEZAL DE SU ATOMIZADOR**

el sabor o la producción de vapor, puede ser momento de reemplazar el cabezal de su atomizador. Se recomienda cambiar el cabezal de su atomizador una vez cada 14 semanas (dependiendo del uso personal).

A fin de obtener el sabor más auténtico del e-líquido, también sugerimos cambiar el cabezal de su atomizador cuando cambie los sabores del e-líquido.

1. Para reemplazar el cabezal del atomizador, ponga su tanque hacia abajo, desenrosque y retire la válvula de flujo de aire girándola en sentido contrario a las agujas del reloj.
2. Mientras aún sostiene la válvula de flujo de aire, sujete la parte superior del cabezal del atomizador y desenrósquelo en sentido contrario a las agujas del reloj para retirarlo de la válvula de flujo de aire.
3. Una vez que haya retirado el atomizador usado, enrosque un nuevo cabezal de atomizador girándolo en el sentido de las agujas del reloj en la válvula de flujo de aire hasta que sienta resistencia. Asegúrese de no ajustar demasiado el cabezal del atomizador ya que esto

puede dañar las juntas de goma y ocasionar fugas.